

# CONTENTS

---

|                                         |             |
|-----------------------------------------|-------------|
| <b>Progene Operator's Manual</b>        | <i>page</i> |
| <b>SAFETY AND INSTALLATION</b>          |             |
| Declaration of conformity               | 3           |
| English                                 | 4           |
| Français                                | 5           |
| Deutsch                                 | 6           |
| Español                                 | 7           |
| <b>THE PROGENE</b>                      | 8           |
| Unpacking                               | 8           |
| Specification                           | 8           |
| Working Conditions                      | 9           |
| Uses of the Progene                     | 10          |
| Heated Lid                              | 10          |
| Tubes or Reaction Vessel                | 10          |
| Cleaning your Progene                   | 12          |
| <b>OPERATION</b>                        | 13          |
| Front Panel Controls                    | 13          |
| Switching On                            | 16          |
| <b>OPERATING MODE</b>                   | 17          |
| Programs                                | 17          |
| Programming the Segments                | 18          |
| Programming the Header                  | 21          |
| Running a Program                       | 23          |
| Pre-Heat Program                        | 24          |
| Printing Profiles                       | 25          |
| Computer Communications                 | 27          |
| Warnings and Messages                   | 28          |
| <b>OPTIONS MODE</b>                     | 30          |
| <b>ADDITIONAL INFORMATION</b>           | 32          |
| Fault Finding                           | 32          |
| Fuses                                   | 32          |
| The Heated Lid Over-temperature Cut-out | 32          |
| Insulation Testing                      | 32          |
| Interchangeable Blocks                  | 33          |
| Accessories                             | 33          |
| Replacement Parts                       | 34          |
| <b>GLOSSARY</b>                         | 35          |
| Program Record Sheet                    | 36          |





Techne (Cambridge) Ltd  
Duxford  
Cambridge  
CB2 4PZ



## Declaration of Conformity

Techne Unit Progene has been designed to comply with the following European Standards:

EN 50081-1:1992 Electromagnetic Compatibility; Generic emission standard.

EN 50082-1:1992 Electromagnetic Compatibility; Generic immunity standard  
(Performance criterion B).

EN 61010-1:1993 Safety requirements for electrical equipment for measurement, control and  
laboratory use.

EN 61010-2-010:1995 Particular requirements for laboratory equipment for the heating of  
materials.

I have made all reasonable enquiries regarding the unit stated and its conformance to the  
following EU directives:

Low Voltage directive, 73/23/EEC and amendment 93/68/EEC, and

EMC Directive 89/336/EEC and amendments 91/263/EEC 92/31/EEC and 93/68/EEC.

To the best of my knowledge and belief these units conform to these directives.



This Declaration is controlled under an ISO 9001:1994 system certificated by BSI Quality  
Assurance, certificate number FM13585.

Signature

*BC Coombes*

Name

B C Coombes

Position

Quality Manager

Issue 4

30/01/98

## Introduction

Please read all the information in this booklet before using the unit.

## Warning

HIGH TEMPERATURES ARE DANGEROUS: they can cause serious burns to operators and ignite combustible material.

Techne have taken great care in the design of these units to protect operators from hazards, but users should pay attention to the following points:

- USE CARE AND WEAR PROTECTIVE GLOVES TO PROTECT HANDS;
- DO NOT put hot objects on or near combustible objects;
- DO NOT operate the unit close to inflammable liquids or gases;
- DO NOT place any liquid directly in your unit;
- At all times USE COMMON SENSE.

## Operator Safety

All users of Techne equipment must have available the relevant literature needed to ensure their safety.

It is important that only suitably trained personnel operate this equipment, in accordance with the instructions contained in this manual and with general safety standards and procedures. If the equipment is used in a manner not specified by Techne the protection provided by the equipment to the user may be impaired.

All Techne units have been designed to conform to international safety requirements and are fitted with an overtemperature cutout. On some models, the cutout is adjustable and should be set to suit the application. On all other models the cutout is preset to protect the unit.

If a safety problem should be encountered, switch off at the mains socket and remove the plug from the supply.

## Installation

1. All Techne units are supplied with a power cable. This may be integral or plug-in.
2. Before connecting the mains supply, check the voltage against the rating plate. Connect the mains cable to a suitable plug according to the table below. **Note that the unit must be earthed to ensure proper electrical safety.**

| Connections | 220/240V     | 110/120V |
|-------------|--------------|----------|
| Live        | Brown        | Black    |
| Neutral     | Blue         | White    |
| Earth       | Green/yellow | Green    |

The fused plug supplied with the mains lead for use in the UK is fitted with the following value fuse to protect the cable:

230V UK 5 AMP

The fuse in the unit protects the unit and the operator.

Note that units marked 230V on the rating plate work at 220V; units marked 120V work at 110V. In both cases, however, the heating rate will degrade by approximately 8%. The rating plate is on the rear of the unit.

3. Plug the mains cable into the socket on the rear of the unit.
4. Place the unit on a suitable bench or flat workspace, or in a fume cupboard if required, ensuring that the air inlet vents on the underside are free from obstruction.
5. Note that the following symbols may be next to the indicator lamps on the front panel of the units and have the following meanings:

 : the power indicator

 : the heater indicator

 : the overtemperature indicator

6. Symbols on or near the power switch of the unit have the following meanings:

I : mains switch On

O : mains switch Off

## After use

When you have finished heating samples, remember that parts of the unit – the tubes, blocks and associated accessories – may be very hot. Take the precautions listed earlier.

## Guarantee

The unit is guaranteed against any defect in material or workmanship for the period specified on the enclosed guarantee card. This period is from the date of purchase, and within this period all defective parts will be replaced free of charge provided that the defect is not the result of misuse, accident or negligence. Servicing under this guarantee should be obtained from the supplier.

Notwithstanding the description and specification(s) of the units contained in the User's Manual, Techne (Cambridge) Limited hereby reserves the right to make such changes as it sees fit to the units or to any component of the units.

This Manual has been prepared solely for the convenience of Techne (Cambridge) Limited customers and nothing in this Instruction Book shall be taken as a warranty, condition or representation concerning the description, merchantability, fitness for purpose or otherwise of the units or components.

## User maintenance

NOTE THAT THIS EQUIPMENT SHOULD ONLY BE DISMANTLED BY PROPERLY TRAINED PERSONNEL. REMOVING THE SIDE, FRONT OR REAR PANELS EXPOSES POTENTIALLY LETHAL MAINS VOLTAGES. THERE ARE NO USER MAINTAINABLE PARTS WITHIN THE EQUIPMENT.

In the unlikely event that you experience any problems with your unit which cannot easily be remedied, you should contact your supplier and return the unit if necessary. Please include any details of the fault observed and remember to return the unit in its original packing. Techne accept no responsibility for damage to units which are not properly packed for shipping: if in doubt, contact your supplier. See the Decontamination Certificate supplied with your unit.

### 1. Cleaning

Before cleaning your unit ALWAYS disconnect from the power supply and allow to cool below 50° C.

Your unit can be cleaned by wiping with a damp soapy cloth. Care should be exercised to prevent water from running inside the unit. Do not use abrasive cleaners.

### 2. Overtemperature cutout

The overtemperature cutout may be a sensitive mechanical device and mechanical shock can cause it to trip.

- In the event of no heater power, check the mains plug and lead, then reset the cutout control (if this applies to your unit).
- Repeated operation of the cutout indicates a serious fault: you may need to return the unit to your supplier for repair.

### 3. Fuses

Your unit is protected by one or two fuses. These should only be changed by suitably qualified personnel.

If the fuses blow persistently, a serious fault is indicated and you may need to return the unit to your supplier for repair.

## Contact Information

For technical, sales or servicing information, contact your local Techne dealer or,

Techne (Cambridge) Limited, Duxford,  
CAMBRIDGE, CB2 4PZ, United Kingdom.

Telephone: 01223 832401

Telefax: 01223 836838

Service: 01223 836950 24 hour answer machine

e-mail: sales@techneuk.com

Web site: www.techneuk.co.uk

or,

Techne Incorporated, University Park Plaza,  
743 Alexander Road, Princeton, New Jersey,  
08540-6328, USA.

Telephone: (609) 452-9275

Toll free: 1-800-225-9243

Telefax: (609) 987-8177

e-mail: techsupport@techneusa.com

Web site: www.techneusa.com

## Introduction

Veillez lire attentivement toutes les instructions de ce document avant d'utiliser l'appareil.

## Avertissement

**DANGER DE TEMPERATURES ELEVEES** : les opérateurs peuvent subir de graves brûlures et les matériaux combustibles risquent de prendre feu.

Techne a apporté un soin tout particulier à la conception de ces appareils de façon à assurer une protection maximale des opérateurs, mais il est recommandé aux utilisateurs de porter une attention spéciale aux points suivants :

- PROCÉDER AVEC SOIN ET PORTER DES GANTS POUR SE PROTÉGER LES MAINS.
- NE PAS poser d'objets chauds sur ou près de matériaux combustibles.
- NE PAS utiliser l'appareil à proximité de liquides ou de gaz inflammables.
- NE PAS verser de liquide directement dans l'appareil.
- FAIRE TOUJOURS PREUVE DE BON SENS.

## Sécurité de l'opérateur

Tous les utilisateurs de produits Techne doivent avoir pris connaissance des manuels et instructions nécessaires à la garantie de leur sécurité.

Important : cet appareil doit impérativement être manipulé par un personnel qualifié et utilisé selon les instructions données dans ce document, en accord avec les normes et procédures de sécurité générales. Dans le cas où cet appareil ne serait pas utilisé selon les consignes précisées par Techne, la protection pour l'utilisateur ne serait alors plus garantie.

Tous les appareils Techne sont conçus pour répondre aux normes de sécurité internationales et sont dotés d'un coupe-circuit en cas d'excès de température. Sur certains modèles, ce coupe-circuit est réglable pour s'adapter à l'application désirée. Sur d'autres modèles, il est pré-réglée en usine pour assurer la protection de l'appareil.

Dans le cas d'un problème de sécurité, coupez l'alimentation électrique au niveau de la prise murale et enlevez la prise connectée à l'appareil.

## Installation

1. Tous les appareils Techne sont livrés avec un câble d'alimentation qui peut être intégré à l'appareil ou à raccorder.
2. Avant de brancher l'appareil, vérifiez la tension requise indiquée sur la plaque d'identification. Raccordez le câble électrique à la prise appropriée en vous reportant au tableau ci-dessous. **Il est important que l'appareil soit relié à la terre pour assurer la protection électrique requise.**

|            |            |           |
|------------|------------|-----------|
| Connexions | 220/240 V  | 110/120 V |
| Phase      | Marron     | Noir      |
| Neutre     | Blue       | Blanc     |
| Terre      | Vert/juane | Vert      |

Le fusible à l'intérieur de l'appareil est destiné à assurer la protection de l'appareil et de l'opérateur.

**Remarque** : les appareils dont la plaque indique 230 V peuvent fonctionner sur 220 V, et ceux dont la plaque indique 120 V peuvent fonctionner sur 110 V. Dans les deux cas cependant, la capacité de chauffage diminuera d'environ 8 %. La plaque d'identification se trouve à l'arrière de l'appareil.

3. Raccordez le câble d'alimentation à la prise située à l'arrière de l'appareil.
4. Placez l'appareil sur un plan de travail ou surface plane, ou le cas échéant, dans une hotte d'aspiration, en s'assurant que les trous d'aération situés sous l'appareil ne sont pas obstrués.
5. Les symboles ci-dessous situés à côté des témoins lumineux sur la face avant de l'appareil ont la signification suivante :

|                                                                                     |                                 |
|-------------------------------------------------------------------------------------|---------------------------------|
|  | : témoin d'alimentation         |
|  | : témoin de chauffage           |
|  | : témoin d'excès de température |

6. Les symboles situés sur ou à côté de l'interrupteur de l'appareil ont la signification suivante :

**I** : arrêt  
**O** : marche

## Après utilisation

Lorsque vous avez fini de chauffer les échantillons, n'oubliez pas que certaines parties de l'appareil - les éprouvettes, leurs supports et autres accessoires - risquent d'être très chaudes. Il est donc recommandé de toujours prendre les précautions citées plus haut.

## Garantie

L'appareil est garanti contre tout défaut ou vice de fabrication pour la durée figurant sur la carte de garantie, à compter de la date d'achat de l'appareil. Au cours de cette période, toutes les pièces défectueuses seront remplacées gratuitement, dans la mesure où la défaillance n'est pas due à une mauvaise utilisation, un accident ou une négligence. Toute réparation sous garantie sera effectuée par le fournisseur.

Malgré la description et les spécifications de l'appareil données dans le manuel de l'utilisateur, Techne (Cambridge) Limited se réserve le droit d'effectuer les changements nécessaires à l'appareil ou à tout élément qui entre dans sa composition.

Ce manuel a été exclusivement rédigé à l'attention des clients de Techne (Cambridge) Limited, et aucun élément de ce guide d'instructions ne peut être utilisé comme garantie, condition ou représentation concernant la description, commercialisation, adaptation aux conditions d'utilisation ou autre des appareils ou de leurs composants.

## Entretien utilisateur

**IMPORTANT : CET APPAREIL NE PEUT ETRE DEMONTE QUE PAR DU PERSONNEL QUALIFIE.**

**LORSQUE LES PANNEAUX AVANT, ARRIERE ET LATÉRAUX SONT DEMONTES, L'OPERATEUR EST EXPOSE A DES TENSIONS QUI PEUVENT ETRE MORTELLES.**

**CET APPAREIL NE CONTIENT AUCUN ELEMENT QUI DEMANDE UN ENTRETIEN DE LA PART DE L'UTILISATEUR.**

Dans le cas peu probable où votre appareil présente un défaut de fonctionnement auquel il est difficile de remédier, il est alors préférable de contacter votre fournisseur et, le cas échéant, de renvoyer le matériel. Veuillez inclure une description détaillée du problème constaté et retourner l'appareil dans son emballage d'origine. Techne ne sera pas tenu responsable des dommages subis par tout appareil dont l'emballage est inadéquat pour le transport. Pour plus de sûreté, contactez votre fournisseur. Voir le certificat de décontamination livré avec le produit.

### 1. Nettoyage

Avant de nettoyer l'appareil, assurez-vous TOUJOURS que le câble d'alimentation est déconnecté et laissez la température redescendre en dessous de 50 °C.

Utilisez un chiffon imprégné d'eau savonneuse pour nettoyer l'appareil. Veillez à ne pas introduire d'eau dans l'appareil. N'utilisez pas de produits abrasifs.

### 2. Coupe-circuit d'excès de température

Ce dispositif est un mécanisme très sensible et il peut se déclencher sous l'effet d'un choc mécanique.

- En l'absence de puissance de chauffe, vérifiez la prise et le câble d'alimentation puis réglez la commande du coupe-circuit (si votre appareil est doté de ce mécanisme).
- Si la sécurité se déclenche trop souvent, il s'agit d'un problème plus sérieux. Nous vous conseillons dans ce cas de prendre contact avec votre fournisseur pour réparation.

### 3. Fusibles

La protection de l'appareil est assurée par un ou deux fusibles dont le remplacement ne peut être effectué que par un personnel qualifié.

Si les fusibles sautent sans arrêt, il s'agit d'un problème sérieux. Nous vous conseillons dans ce cas de prendre contact avec votre fournisseur pour réparation.

## Einleitung

Bitte lesen Sie diese Bedienungsanleitung komplett bevor Sie dieses Gerät benutzen.

## Warnung

HOHE TEMPERATUREN SIND GEFÄHRlich: sie können dem Bediener ernsthafte Verletzungen zufügen und brennbare Materialien können sich leicht entzünden.

Techne hat bei der Konstruktion dieses Gerätes sehr darauf geachtet, daß der Bediener vor Gefahren geschützt ist. Dennoch sollten Sie auf die folgenden Punkte achten:

- SEIEN SIE VORSICHTIG UND TRAGEN SIE SCHUTZHANDSCHUHE
- Legen Sie heiße Gegenstände NICHT auf oder in die Nähe von leicht brennbaren Materialien; vermeiden Sie Arbeiten in der Nähe von leicht entzündbaren Flüssigkeiten oder Gasen.
- Bringen sie KEINE Flüssigkeiten direkt in Ihr Gerät.
- Benutzen Sie immer den normalen Menschenverstand

## Sicherheit des Anwenders

Alle Benutzer von Techne Geräten müssen Zugang zu der entsprechenden Literatur haben, um ihre Sicherheit zu gewähren. Es ist wichtig, daß diese Geräte nur von entsprechend geschultem Personal betrieben werden, das die in dieser Gebrauchsanweisung enthaltenen Maßnahmen und allgemeine Sicherheitsbestimmungen und -vorkehrungen beachtet. Wenn das Gerät anders eingesetzt wird als vom Hersteller empfohlen, kann dies die persönliche Sicherheit des Anwenders beeinträchtigen. Die Geräte von Techne entsprechen den internationalen Sicherheitsbestimmungen und sind mit einem automatischen Übertemperaturabschalter ausgestattet. Bei einigen Modellen ist der Übertemperaturabschalter verstellbar und sollte je nach Anwendung entsprechend eingestellt werden. Bei allen anderen Modellen ist der Temperaturschutz voreingestellt um Schäden am Gerät zu vermeiden. Wenn ein Sicherheitsproblem auftreten sollte, muß das Gerät ausgeschaltet und vom Stromnetz getrennt werden.

## Installation

1. Alle Techne Geräte werden mit einem Stromanschlußkabel geliefert. Dieses ist entweder fest mit dem Gerät verbunden oder zum Einstecken.
2. Vergleichen Sie, ob die Spannung Ihrer Stromversorgung mit den Angaben auf dem Typenschild des Gerätes übereinstimmen. Verbinden Sie das Stromanschlußkabel mit einer geeigneten Stromversorgung gemäß der nächstehenden Tabelle. Achtung: Das Gerät muß geerdet sein, um die elektrische Sicherheit zu gewährleisten!

|              |           |          |
|--------------|-----------|----------|
| Verbindungen | 220/240V  | 110/120V |
| Stromführend | Braun     | Schwarz  |
| Neutral      | Blau      | Weiß     |
| Erde         | Grün/Gelb | Grün     |

Geräte, die für 230 Volt ausgelegt sind, können auch bei 220 Volt arbeiten, Geräte für 120 Volt auch bei 110 Volt. In beiden Fällen verringert sich die Aufheizrate um ca. 8%. Das Typenschild befindet sich hinten am Gerät.

3. Stecken Sie das Stromkabel in die vorgesehene Buchse hinten am Gerät.
4. Stellen Sie das Gerät auf eine ebene Arbeitsfläche bzw. (falls erforderlich) unter einen Laborabzug. Beachten Sie, daß die Entlüftungsrippen an der Geräteunterseite immer frei zugänglich sind.
5. Wenn die Anzeigenlämpchen an der Vorderseite leuchten, hat dies folgende Bedeutung:

-  : Gerät ist eingeschaltet
-  : Gerät heizt
-  : Übertemperaturschutz ist ausgelöst

6. Die Symbole auf oder neben dem EIN/AUS-Schalter an der Geräterückseite bedeuten:

- I : An
- O : Aus

## Nach dem Gebrauch

Vergessen Sie nicht, daß Teile des Gerätes (die Gefäße, die Blöcke und andere Zubehörteile) nach dem Erhitzen von Proben noch sehr heiß sein können. Bitte beachten Sie die oben genannten Vorsichtsmaßnahmen.

## Garantie

Die Garantiedauer des Gerätes ist auf der beiliegenden Garantiekarte angegeben und schließt Fehler im Material oder der Verarbeitung ein. Die Garantiedauer beginnt am Tag des Einkaufs. Sämtliche defekte Teile werden innerhalb dieses Zeitraumes kostenlos ersetzt unter der Voraussetzung, daß dem Defekt keine unsachgemäße Handhabung, Fahrlässigkeit oder ein Unfall zugrundeliegt. Der unter diese Garantie fallende Service wird vom Lieferanten geleistet.

Ungeachtet der in dieser Gebrauchsanweisung enthaltenen Beschreibungen und Spezifikationen, behält sich Techne (Cambridge) Limited hiermit das Recht vor, Änderungen an den Geräten bzw. an einzelnen Geräteteilen durchzuführen.

Diese Gebrauchsanleitung wurde ausschließlich dazu erstellt, um Kunden die Handhabung der Techne-Geräte zu erleichtern. Nichts in dieser Gebrauchsanleitung darf als Garantie, Bedingung oder Voraussetzung verstanden werden, sei es die Beschreibung, Marktängigkeit, Zweckdienlichkeit oder sonstiges bezüglich der Geräte oder deren Bestandteile.

## Wartung durch den Bediener

BEACHTEN SIE, DASS DIESES GERÄT NUR VON TECHNISCHEN FACHKRÄFTEN GEÖFFNET UND DEMONTIERT WERDEN DARF.

DURCH ENTFERNEN DES GEHÄUSES ODER GEHÄUSETEILEN SIND BAUTEILE MIT LEBENGEFÄHRlichen SPANNUNGEN FREI ZUGÄNGlich.

IM INNEREN DES GERÄTES BEFINDEN SICH KEINE TEILE, DIE VOM ANWENDER GEWARTET WERDEN MÜSSEN.

Falls Ihr Gerät nicht ordnungsgemäß arbeitet, wenden Sie sich an Ihren Lieferanten oder senden Sie das Gerät wenn nötig zurück. Fügen Sie eine genaue Beschreibung des Defektes bei. Verpacken Sie das Gerät möglichst im Originalkarton. Bitte beachten Sie, daß Techne und thermo-DUX keine Haftung bei Transportschäden aufgrund unzureichender Verpackung übernehmen. Setzen Sie sich im Zweifelsfall mit Ihrem Lieferanten in Verbindung. Bitte beachten Sie die Entgiftungsbescheinigung, die Sie mit dem Gerät erhalten haben.

### 1. Reinigen

Bevor Sie Ihr Gerät reinigen, sollten Sie

- zuerst den Netzstecker ziehen
- das Gerät unter 50°C abkühlen lassen.

Ein feuchtes Tuch mit Seifenlösung reinigt Ihr Gerät am besten. Achten Sie darauf, daß kein Wasser in das Gerät gelangt. Verwenden Sie keine Scheuermittel.

### 2. Übertemperaturabschalter

- Der Übertemperaturschutz ist ein empfindliches mechanisches Teil. Schon eine Erschütterung kann diesen auslösen.
- Falls die Heizung nicht funktioniert, überprüfen Sie zuerst Netzstecker und Kabel. Setzen Sie dann den Übertemperaturabschalter (an der Rückseite des Gerätes) wieder zurück, indem Sie den roten Knopf einmal bis zum Anschlag drücken.
- Wenn der Übertemperaturabschalter wiederholt auslöst, liegt ein größerer Defekt vor. Das Gerät muß zur Reparatur an Ihren Lieferanten eingesandt werden.

### 3. Sicherungen

Die Stromzuleitung ist durch ein oder zwei Sicherungen geschützt. Diese sollten nur durch qualifiziertes Fachpersonal ausgetauscht werden. Wenn die Sicherung wiederholt durchbrennt, liegt ein größerer Defekt vor. Das Gerät muß zur Reparatur an Ihren Lieferanten eingesandt werden.

## Introducción

Le rogamos lea cuidadosamente la información contenida en este folleto antes de manipular el aparato.

## Aviso

LAS TEMPERATURAS ELEVADAS SON PELIGROSAS: pueden causar graves quemaduras y provocar fuego en materiales combustibles.

Techne ha puesto gran cuidado en el diseño de estos aparatos para proteger al usuario de cualquier peligro; aún así se deberá prestar atención a los siguientes puntos:

- EXTREME LAS PRECAUCIONES Y UTILICE GUANTES PARA PROTEGERSE LAS MANOS;
- NO coloque objetos calientes encima o cerca de objetos combustibles;
- NO maneje el aparato cerca de líquidos inflamables o gases;
- NO introduzca ningún líquido directamente en el aparato;
- UTILICE EL SENTIDO COMUN en todo momento.

## Seguridad del usuario

Todos los usuarios de equipos Techne deben disponer de la información necesaria para asegurar su seguridad.

De acuerdo con las instrucciones contenidas en este manual y con las normas y procedimientos generales de seguridad, es muy importante que sólo personal debidamente capacitado opere estos aparatos. De no ser así, la protección que el equipo le proporciona al usuario puede verse reducida.

Todos los equipos Techne han sido diseñados para cumplir con los requisitos internacionales de seguridad y traen incorporados un sistema de desconexión en caso de sobretemperatura. En algunos modelos el sistema de desconexión es variable, lo que le permite elegir la temperatura según sus necesidades. En otros, el sistema de desconexión viene ya ajustado para evitar daños en el equipo.

En caso de que surgiera un problema de seguridad, desconecte el equipo de la red.

## Instalación

1. Todos los aparatos Techne se suministran con un cable de alimentación. Puede ser fijo o independiente del aparato.
2. Antes de conectarlo, compruebe que el voltaje corresponde al de la placa indicadora. Conecte el cable de alimentación a un enchufe adecuado según la tabla expuesta a continuación. El equipo debe estar conectado a tierra para garantizar la seguridad eléctrica.

|            |                |          |
|------------|----------------|----------|
| Conexiones | 220/240V       | 110/120V |
| Línea      | Marrón         | Negro    |
| Neutro     | Azul           | Blanco   |
| Tierra     | Verde/amarillo | Verde    |

El enchufe suministrado con el cable de alimentación viene equipado con un fusible del siguiente valor para proteger el cable:

230V Reino Unido 5AMP

El fusible una vez instalado protege tanto al equipo como al usuario.

Asegúrese de que los equipos marcados 230V en la placa indicadora funcionan a 220V y de que los equipos marcados 120V funcionan a 110V. No obstante, en ambos casos la velocidad de calentamiento se verá reducida en un 8% aproximadamente. La placa indicadora está situada en la parte posterior del equipo.

3. Conecte el cable a la toma de tensión en la parte posterior del equipo.
4. Sitúe el aparato en un lugar apropiado tal como una superficie de trabajo plana, o si fuera necesario incluso en una campana con extractor de humos, asegurándose de que las entradas de aire en la parte inferior no queden obstruidas.
5. Los símbolos, que pueden aparecer junto a las luces indicadoras en el panel frontal del equipo, tienen los siguientes significados:

|                                                                                     |                                 |
|-------------------------------------------------------------------------------------|---------------------------------|
|  | : Indicador de potencia         |
|  | : Indicador del calor           |
|  | : Indicador de sobretemperatura |

6. Los símbolos que se encuentran en o cerca del interruptor de alimentación tienen los siguientes significados:

|   |                                   |
|---|-----------------------------------|
| I | : Interruptor principal encendido |
| O | : Interruptor principal apagado   |

## Después de su uso

Cuando haya finalizado el calentamiento de muestras, recuerde que las piezas del equipo, tales como tubos, bloques y demás accesorios, pueden estar muy calientes. Tome las precauciones mencionadas anteriormente.

## Garantía

Este aparato está garantizado contra cualquier defecto material o de fabricación durante el periodo especificado en la tarjeta de garantía adjunta. Este plazo inicia a partir de la fecha de compra, y dentro de este periodo todas las piezas defectuosas serán reemplazadas gratuitamente siempre que el defecto no sea resultado de un uso incorrecto, accidente o negligencia. Mientras se encuentre bajo garantía las revisiones las debe llevar a cabo el proveedor.

A pesar de la descripción y las especificaciones de los aparatos contenidas en el Manual del Usuario, Techne (Cambridge) Limited se reserva por medio de este documento el derecho a efectuar los cambios que estime oportunos tanto en los aparatos como en cualquier componente de los mismos.

Este manual ha sido preparado exclusivamente para los clientes de Techne (Cambridge) Limited y nada de lo especificado en este folleto de instrucciones se tomará como una garantía, condición o aseveración de la descripción, comerciabilidad o adecuación para cualquier fin específico de los aparatos o sus componentes.

## Mantenimiento

ESTE APARATO DEBE SER DESMONTADO SOLO Y EXCLUSIVAMENTE POR PERSONAL DEBIDAMENTE CAPACITADO.

EL RETIRAR LOS PANELES LATERALES, FRONTALES O TRASEROS SUPONE DEJAR AL DESCUBIERTO TENSION DE LA RED PELIGROSA.

EL EQUIPO NO CONSTA DE NINGUNA PIEZA DE CUYO MANTENIMIENTO SE PUEDA ENCARGAR EL USUARIO.

En el caso improbable de que experimentara algún problema con su aparato que no pudiera resolver con facilidad, debería ponerse en contacto con su proveedor y devolverlo si fuera necesario. Indique de forma detallada todos los defectos que haya notado y devuelva el equipo en su embalaje original. Techne no aceptará responsabilidad alguna por daños causados en equipos que no estuvieran debidamente embalados para su envío; si tuviera alguna duda, póngase en contacto con su proveedor. Sírvese consultar el Certificado de Descontaminación suministrado con su aparato.

### 1. Limpieza

Antes de limpiar su aparato, desconéctelo SIEMPRE de la fuente de alimentación y permita que se enfríe por debajo de los 50°C.

Este aparato se puede limpiar pasándole un paño húmedo enjabonado. Hágalo con cuidado para evitar que caiga agua dentro del mismo. No utilice limpiadores abrasivos.

### 2. Desconexión en caso de sobretemperaturas

El sistema de desconexión en caso de sobretemperaturas es un dispositivo mecánico sensible (una sacudida mecánica podría desconectarlo).

- Si el calefactor no recibiera alimentación, compruebe el enchufe y el cable de la toma de corriente; a continuación vuelva a ajustar el control del dispositivo (si su equipo lo lleva montado).
- Una desconexión repetida indicaría una avería grave; puede que tenga que devolverle el aparato a su proveedor para su reparación.

### 3. Fusibles

Su aparato está protegido por uno o dos fusibles. Sólo deben cambiarlos personal debidamente capacitado.

Si los fusibles se fundieran repetidamente, esto indicaría una avería grave y puede que tuviera que devolverle el aparato a su proveedor para su reparación.

## THE PROGENE

---

**Before using the Progene make sure you have read this manual carefully.** If there is any doubt relating to the proper use of this equipment, the staff at Techne or your supplier will be pleased to assist you.

The Progene provides the researcher with the means of accurately controlling the temperature profile of samples. It has many scientific applications, including DNA amplification and sequencing. The Progene can cycle samples between 4°C (39°F) and 99°C (210°F).

The Progene is programmed by means of an integral keypad and LCD display. A program, which can be recalled from memory, consists of:

- a series of specified temperatures in °C
- the times for which each specified temperature will be held (Hold Times)
- the desired heating or cooling rates, in °C/min, between each specified temperature
- whether the times and/or the temperatures are to increase or decrease when a program is repeated.

The memory can store up to 50 programs which can be:

- linked together
- repeated a number of times in sequence.

## Unpacking

---

When unpacking the unit, check that the following have been removed from the packing:

- |                                 |                              |
|---------------------------------|------------------------------|
| • The Progene unit              | • A Hot Box                  |
| • Mains cable                   | • Guarantee card             |
| • The Progene Operator's Manual | • The Progene Reference Card |

Make sure you keep the original packing, in case you ever need to return it for service or repair. Techne accepts no responsibility for damage incurred unless the unit is correctly packed and transported in its original packing.

## Specification

---

Although the unit is designed to go down to 4°C, at this temperature the coolers are working very hard against room temperature. You will prolong the life of the coolers if you have the end of a run hold temperature nearer to ambient, say 15°C.

|                                                                |                          |
|----------------------------------------------------------------|--------------------------|
| Temperature range                                              | 4°C to 99°C              |
| Temperature control precision                                  | ±0.1°C                   |
| Block uniformity (over full range)                             | ± 0.5°C                  |
| Maximum Hold Time                                              | 99 hrs 59 min            |
| Temperature accuracy                                           | ±1°C                     |
| Heating rate, between 55°C and 90°C on a 50°C to 95°C segment: |                          |
| 25 x 0.2 ml micro tubes or multiwell plates                    | 2.8°C/sec                |
| 20 x 0.5ml microcentrifuge tubes                               | 2.5°C/sec                |
| Cooling rate, between 90°C & 55°C on a 95°C to 50°C segment:   |                          |
| 25 x 0.2 ml micro tubes or multiwell plates                    | 2.2°C/sec                |
| 20 x 0.5ml microcentrifuge tubes                               | 2.0°C/sec                |
| Programmable ramp rate (heat or cool)                          | from 1°C/min to 60°C/min |
| Programmable ramp rate resolution                              | 1°C                      |



|                                           |                                    |
|-------------------------------------------|------------------------------------|
| Incremental/decremental Temperature       | -5.5°C to +5.6°C                   |
| Incremental/decremental Segment Hold Time | -99 to +99 in one second intervals |
| Number of Programs                        | 50                                 |
| Number of segments per program            | 9                                  |
| Maximum total number of segments          | 143                                |
| Number of repeat cycles per program       | 99                                 |
| Program to program linking                | Yes                                |
| End of program alarm                      | Yes                                |
| Pause button                              | Yes                                |
| Auto re-start                             | Yes                                |
| Power consumption                         | 230W                               |

### Dimensions

|        |       |
|--------|-------|
| Height | 170mm |
| Width  | 155mm |
| Length | 380mm |

### Parallel Port

An 80-column PC-compatible printer is required to print out profile data. A Centronics printer socket is provided at the rear of the unit for this purpose. When the printer is connected, profile information is printed out as the run progresses.

### Serial Port

This socket is provided for RS232 printer link.

### Specification for the Integral Heated Lid

|                                                                   |                                                                     |
|-------------------------------------------------------------------|---------------------------------------------------------------------|
| Temperature range                                                 | Fixed control, at the top of the tubes, 105°C                       |
| Temperature stability                                             | ±1°C                                                                |
| Over-temperature cutout                                           | Fixed at 145°C (plate temperature of 105°C, top of the tubes 105°C) |
| Temperature sensor                                                | Thermistor                                                          |
| Heater Type                                                       | Silicone rubber mat                                                 |
| Heater Power                                                      | 33W                                                                 |
| Warm up time                                                      | 3 min approximately (ambient to 105°C)                              |
| The Heated Lid only comes on if the set temperature is above 35°C |                                                                     |

### Voltage

The units marked 100V - 120V will work at any voltage between 90V and 130V. The units marked 230V will work at any voltage between 210V and 260V. However, the performance will vary and will not necessarily meet the above specification at the extremes of voltage.

### Working conditions

The Progene is designed to work safely under the following conditions:

|                           |                                             |
|---------------------------|---------------------------------------------|
| Ambient temperature range | 5°C to 40°C                                 |
| Humidity                  | Up to 95% relative humidity, non-condensing |

**Note:** The control specifications are quoted at an ambient temperature of 20°C. The specification may deteriorate outside an ambient temperature range of 10°C to 30°C.

Radio frequency interference tested and passed to EN50081-1.  
Immunity Tested and passed to EN50082-1

## Uses of the Progene


---

The Progene has many scientific laboratory applications, including DNA sequencing and PCR. Aspects of the PCR process are claimed in U.S. Patent Nos. 4,683,195, 4,683,202, and 4,965,188. Use of the Progene in such processes does not convey a licence to practice the processes themselves.

## Heated Lid

---

To release the heated lid, push gently down on the opening device using the thumb with the palm of the hand over the lid and the catch will release. If you have tubes in the block or the hot box over it, be careful as the lid will spring open when you press. If there is nothing under the lid it will open more gently.



## Tubes or Reaction Vessel

---

Techne does not recommend any specific tube or reaction vessel other than those described in this Manual. We recommend using reaction volumes between 20 and 200 $\mu$ l. The tubes must withstand a pressure of 1 atmosphere at 100°C.


To test your tubes, put 25 $\mu$ l of water in each of 5 tubes and subject them to a typical thermal cycling protocol. At the end of the cycle, measure the volume remaining, using a micropipet. A loss of more than 1 or 2 $\mu$ l indicates a vapour leak.

The amount of volume loss you observe and the change in reactant concentrations you can tolerate determine the minimum volume that can be used. Typical volume losses of 1 $\mu$ l in 30 cycles allow the use of samples of 20 $\mu$ l or less.


During the final cooldown, a ring of condensation may form above the liquid level but below the top of the sample block. This is not usually a cause for concern, as the condensation does not form during cycling.

## The Hot Box

When you open the pack for your Progene you will find a Hot Box in a labelled plastic bag. Always use the Hot Box over any tubes in the block, it will reduce condensation on the inside of the tubes.



The correct way to put the Hot Box over the samples is so that you can read the words on the top of the hot box from the front of the Progene.




Do not put it in sideways.

## Tubes

If you are using the 0.5ml tubes, because of the compact nature of the block, we recommend only flat top, round lidded tubes such as those supplied by Techne (see page 31). If the top of the tubes is not flat you may get some condensation.


If the lid is not basically round then you may have trouble fitting the tubes in the block and you may have to fit a smaller number of tubes. Always make sure the Heated Lid is balanced even if you have to put in some dummy tubes.

Even with round lidded tubes, the tubes need to be put in the block so that all the hinges are in the same relative place. An example is illustrated here:



## Cleaning your Progene

Before cleaning your unit, disconnect from the power supply and allow to cool to below 50°C.



The heat/cool block, including wells and flat surfaces, should be cleaned regularly to ensure optimum heat transfer to the samples. Always clean the block if there has been a spillage. Use a cloth or cotton buds dipped in a fresh, 50:50 water/isopropanol solution, and make sure that no deposits are left in the wells.

In the case of radioactive spillages, Techne recommend that you use a proprietary cleaning agent and follow the manufacturer's instructions. The heat/cool block is made of aluminium. Therefore, an agent such as Neutracon (from Decon Laboratories Ltd.), suitable for nonferrous metals should be used but remember other parts of the unit are made of ferrous materials and may be damaged by spillage onto them.

You can clean the case of the Progene with a cloth dipped in water or ethanol (methanol or formaldehyde can also be used). No part of the case or cover should be immersed in the solvents. Do not use aggressive solvents such as acetone, or abrasive cleaners.

The blocks can be removed for a more detailed cleaning. Remove the four screws beneath the unit and drop the block/fan assembly down. Unplug the assembly from the wiring and remove the assembly from the unit. Refitting the block/fan assembly is the reverse procedure, be careful of the wires as you refit the block.

## OPERATION


### Front Panel Controls

The control panel of the Progene consists of a membrane keypad, an alphanumeric LCD panel and four status LEDs.


The LCD panel can display two lines of 16 characters each and shows the programmed parameters for the selected mode, or the options available for each function. In Operating mode, the top line gives the Program data (the Header line) and the bottom line shows the Segment data (the Segment line).

The keypad consists of eight keys which 'click' when pressed. Four of these are function keys (**START/STOP**, **MODE**, **EDIT**, **PAUSE**); the others are cursor keys (**LEFT ARROW**, **UP ARROW**, **DOWN ARROW** and **RIGHT ARROW**).


**WARNING** PLEASE NOTE THAT THIS KEYPAD IS EASILY DAMAGED BY SHARP OBJECTS INCLUDING PENS, PENCILS AND SHARP FINGERNAILS. DAMAGE OF THIS TYPE WILL BE CONSIDERED AS MISUSE AND WILL INVALIDATE THE GUARANTEE ON THIS COMPONENT. A diagram of the control panel is shown below:



#### START/STOP Key



Press the **START/STOP** key to start running the currently displayed program; press it again to stop the program. When you press this key to stop the program, the unit cancels the current function and returns to ambient temperature with the main cooling fan switched on.




The LED indicator associated with the **START/STOP** key lights up when the program starts; a second key press stops the program and switches off the LED. The fan switches off automatically after five minutes.

If you wish to stop momentarily before continuing, press the **PAUSE** key, see below.


## MODE Key

When you first power up the Progene, you are automatically placed in Operating mode.



Press the **MODE** key to switch to Options mode; press it again to return to Operating mode.


## EDIT Key




The **EDIT** key is used in combination with the **UP ARROW** and **DOWN ARROW** keys to move between the Segment and Program sections in Operating mode. Once you are programming a segment or program, the **EDIT** key is used in combination with the **RIGHT ARROW** and **LEFT ARROW** keys to insert or delete segments or programs.

You are also sometimes prompted to press the **EDIT** key to confirm data you have entered.

## PAUSE Key




The **PAUSE** key is only active while a program is running. When you press this key, the unit temporarily stops and maintains the block at its current temperature, until you press **PAUSE** again to resume.




The LED indicator associated with the **PAUSE** key lights up when the key is first pressed. A second key press cancels the action and switches off the LED.

Note that you may only use this key in Operating mode while a program is running.

## Cursor Keys




Press the **RIGHT ARROW** and **LEFT ARROW** keys to move between fields.




Press the **UP ARROW** and **DOWN ARROW** keys to select a required value. A single key press increases/decreases the value by one. A three speed scroll is used on each digit except the program number, so hold the key down to move through the numbers more quickly. The program number can only be increased one at a time.

## LEDs




There are two red indicators to show that the **START/STOP** or the **PAUSE** keys have been pressed.

There are two other LED's.



A green one to show that the power is on.



The other to show that the unit is heating (yellow) or that the unit is cooling (green).


Sounder

The Progene is fitted with a sounder to give audible warnings of errors. A ‘beep’ is heard whenever an illegal key-press is made. If the unit discovers a fatal error, a long beep is emitted. (See the section on Warnings and Messages.)

Switching On

---

When the power is switched on, a copyright/version notice similar to the one below is displayed:



The version and suffix ‘C’ will vary depending upon the version of the software and the block type.

**Note:** The version number must always be quoted, together with the unit serial number, when contacting Techne for service.

The Progene may be used in one of two main modes: Operating and Options.

The information displayed on the LCD panel tells you the state of the unit, whether it is currently running a program, or waiting for you to press a key from the keypad.

When the unit is switched on it is automatically placed in Operating mode and displays the last used program on the LCD panel. You can move to the Options mode, provided a program is not running, by pressing the **MODE** key. (See the section headed ‘Options mode’ later in this manual, page 28.)



## OPERATING MODE

In Operating mode, the user writes programs which control the block. When you switch on the Progene, you are automatically put into Operating mode.

The panel displays the last used program and will look something like this:

|                | PROG NO | CYCLES      | LINK TO | INC TEMP  | INC TIME |
|----------------|---------|-------------|---------|-----------|----------|
| <b>HEADER</b>  | 0 1     | 0 2         | 0 1     | - 9 . 9   | 0 0      |
| <b>SEGMENT</b> | 3       | 9 9 . 0     | 4 0     | 0 2 m     | 4 5      |
|                | SEGMENT | TEMPERATURE | RATE    | HOLD TIME |          |


The top line of the LCD display shows the Program data (the Header line) and the bottom line shows the Segment data (the Segment line).

You can run this program as it stands or alter any of its components, or you can select another program.

## Programs


A program may contain up to nine segments. Each Segment can be assigned its own Set Point Temperature, Ramp Rate and Hold Time. The Hold Time and Temperature of each segment may be automatically incremented or decremented between consecutive Cycles. A program can be made to run a group of segments in sequence, for a specified number of Cycles, before linking to another program, or finishing.

Creating a program involves editing both Segment data and Program Header data. First choose a program you wish to edit, then set up the segments, followed by the Header.



To choose a program number you need to place the cursor on the Program Number field. Hold down the **EDIT** key then press the **UP ARROW** key. Use the **LEFT ARROW** key to move between adjacent fields until you are on the Program number field.

|  | PROG NO | CYCLES      | LINK TO | INC TEMP  | INC TIME |
|--|---------|-------------|---------|-----------|----------|
|  | 0 1     | 0 2         | 0 1     | - 9 . 9   | 0 0      |
|  | 3       | 9 9 . 0     | 4 0     | 0 2 m     | 4 5      |
|  | SEGMENT | TEMPERATURE | RATE    | HOLD TIME |          |



Once in the Program Number field use the **UP ARROW** or **DOWN ARROW** key to move through the programs until you reach the one you wish to edit. If you wish to move to the next free program, choose one with a Segment 1 Hold Time of **00m00**. This is the next available program. For example:

|  | PROG NO | CYCLES      | LINK TO | INC TEMP  | INC TIME |
|--|---------|-------------|---------|-----------|----------|
|  | 0 7     | 0 1         | 0 1     | 0 . 0     | 0 0      |
|  | 1       | 4 0 . 0     | MX      | 0 0 m     | 0 0      |
|  | SEGMENT | TEMPERATURE | RATE    | HOLD TIME |          |

The next sections detail how to edit Segments and Headers.

## Programming the Segments

For each segment you must put in the Set Point Temperature, the Heating or Cooling Rate and the length of time to hold (the Hold Time) at the Set Point Temperature.

Note that if you exceed the preset maximum or minimum, see page 29, the value will simply roll round to the next valid number.

### Segment Number

 and  If the cursor is not on the segment line hold down the **EDIT** key and press the **DOWN ARROW** key.

 If the cursor is not on the segment number press the **LEFT ARROW** key to move to it.

The first segment number is always set as 1. After you have completed all the fields, the next segment number is generated automatically by the software.

|         |             |      |           |
|---------|-------------|------|-----------|
| 1       | 4 0 . 0     | M X  | 0 0 m 0 0 |
| SEGMENT | TEMPERATURE | RATE | HOLD TIME |

 Press the **RIGHT ARROW** key to move on to the next field.

### Set Point Temperature

When programming a new segment, the default is set at 40°C.

|         |             |      |           |
|---------|-------------|------|-----------|
| 1       | 4 0 . 0     | M X  | 0 0 m 0 0 |
| SEGMENT | TEMPERATURE | RATE | HOLD TIME |

 or  To change the number, use the **UP ARROW** or **DOWN ARROW** keys as appropriate.

 Press the **RIGHT ARROW** key to move on to the next field.

### Ramp Rate

Ramp rate is the term used to denote the heating or cooling rate in degrees per minute.

When programming a new segment, the default is set at MX (maximum rate).

|         |             |      |           |
|---------|-------------|------|-----------|
| 1       | 9 5 . 0     | M X  | 0 0 m 0 0 |
| SEGMENT | TEMPERATURE | RATE | HOLD TIME |

 or  To change the number, use the **UP ARROW** or **DOWN ARROW** keys as appropriate.

 Press the **RIGHT ARROW** key to move on to the next field.

### Hold Time

Before you can get a program to run you must set a valid time the program should hold the Set Point Temperature once it has been reached. When programming a new segment, the default is set at 00m00.


For Hold Times of less than one hour, the unit may be programd to the nearest second and the display shows minutes and seconds (separated by an 'm'):

|         |             |      |           |
|---------|-------------|------|-----------|
| 1       | 9 9 . 0     | 4 0  | 0 2 m 4 5 |
| SEGMENT | TEMPERATURE | RATE | HOLD TIME |

For Hold Times of more than one hour, the unit may be programmed to the nearest minute and the display will show only hours and minutes (separated by an 'h'). However, the unit is still accurate to one second:

|         |             |      |           |         |
|---------|-------------|------|-----------|---------|
| 1       | 99          | .0   | 40        | 13 h 37 |
| SEGMENT | TEMPERATURE | RATE | HOLD TIME |         |

When the Hold Time reduces to less than one hour, the display changes back to show minutes and seconds.



Press the **UP ARROW** or the **DOWN ARROW** key to select the appropriate Time.


If you require Increment/Decrement Time or Increment/Decrement Temperature follow the next sections.



If not press the **RIGHT ARROW** key to accept the set values for the Segment. Then follow the section 'Further Segments'.

### Increment/Decrement Temperature

Under normal circumstances, the Hold Temperature of all segments is constant. However, it is possible to automatically increment or decrement the temperature of a specified segment of a program by indicating an increment/decrement value in tenths of a degree in this field.




If you require Increment/Decrement Temperature, hold down the **EDIT** key and press the **UP ARROW** key.



Press the **LEFT ARROW** key to move onto the Inc Temp field.

|         |        |         |          |          |
|---------|--------|---------|----------|----------|
| PROG NO | CYCLES | LINK TO | INC TEMP | INC TIME |
| 01      | 01     | E       | 0.0      | 00       |



Press the **UP ARROW** or **DOWN ARROW** keys as appropriate to give the increment or decrement required.

The Hold Temperature of the incremented/decremented segment is the defined Hold Temperature plus the summation of the increments/decrements. The first cycle is never incremented/decremented, only subsequent Cycles.

**Note:** If you select a decrement, the Hold Temperature is prevented from falling below 4°C. If you select an increment, the Hold Temperature is prevented from rising above 99°C.


### Increment/Decrement Time

Under normal circumstances, the Hold Time of all segments is constant. However, it is possible to automatically increment or decrement the duration of a specified segment of a program by indicating an increment/decrement value in seconds in this field.



Press the **RIGHT ARROW** key to move onto the Inc Time field.

|         |        |         |          |          |
|---------|--------|---------|----------|----------|
| PROG NO | CYCLES | LINK TO | INC TEMP | INC TIME |
| 01      | 01     | E       | 0.0      | 00       |




Press the **UP ARROW** or **DOWN ARROW** keys as appropriate to give the increment or decrement required.

The Hold Time of the incremented/decremented segment is the defined Hold Time plus the summation of the increments/decrements. The first cycle is never incremented/decremented, only subsequent Cycles.

**Note:** If you select a decrement, the Hold Time is prevented from falling below one second.

The following diagram shows the effect of applying an increment to segment 3 over five cycles.



 and  Hold down the **EDIT** key and press the **DOWN ARROW** key. Move the cursor to the Hold Time field then to accept the Segment with the values set, press the  **RIGHT ARROW** key and follow the next section

### Further Segments

 Follow the procedure described above to set values for as many segments as necessary (up to nine). To indicate the final segment in any program, accept the default value of 0 as the Hold Time by pressing the **RIGHT ARROW** key when you get to this field.

|         |   |             |   |      |   |           |   |   |   |   |   |
|---------|---|-------------|---|------|---|-----------|---|---|---|---|---|
| 2       | 4 | 0           | . | 0    | M | X         | 0 | 0 | m | 0 | 0 |
| SEGMENT |   | TEMPERATURE |   | RATE |   | HOLD TIME |   |   |   |   |   |

 nor  It is important to note, however, that if the time field is altered, you cannot use the **UP ARROW** or **DOWN ARROW** keys to get it back to 0. This is a safety feature that has been included to avoid accidentally ending a program. If you make any mistakes, you must delete the segment and start again. (See below for details.)

If you require more than nine segments, follow the procedure above but when you edit the Header put Link To a second program. Then set up the second program. See Page 20.


If you make a mistake or you wish to insert or delete segments in a program, follow the instructions below.

## Adding a Segment

To insert a segment into an existing program, make sure you are in Operating mode with the cursor on the segment number immediately before the one you wish to insert.

|         |             |    |      |    |           |
|---------|-------------|----|------|----|-----------|
| 3       | 60          | .0 | MX   | 00 | m12       |
| SEGMENT | TEMPERATURE |    | RATE |    | HOLD TIME |

For example, if the cursor is on segment number 3, the new segment will be numbered 3 and the former 3 becomes 4. You may only insert a new segment prior to one that has already been programmed.



Hold down the **EDIT** key, then press the **RIGHT ARROW** key to insert the new segment. Follow the normal procedure to program it. If you make a mistake or change your mind, follow the procedure described below to delete the segment.


If you try to insert a new segment and the maximum number of segments already exists, a beep is heard and the following error message is displayed:

|             |             |         |          |           |
|-------------|-------------|---------|----------|-----------|
| PROG NO     | CYCLES      | LINK TO | INC TEMP | INC TIME  |
| Memory Full |             |         |          |           |
| SEGMENT     | TEMPERATURE | RATE    |          | HOLD TIME |

You must delete an existing segment before inserting a new one. Press any key to clear the screen.

## Deleting a Segment

To delete a segment from an existing program, make sure you are in Operating mode and the cursor is on the Segment Number you wish to delete. Hold down the **EDIT** key, then press the **LEFT ARROW** key. A message appears asking you to confirm the deletion:




|         |               |         |          |           |
|---------|---------------|---------|----------|-----------|
| PROG NO | CYCLES        | LINK TO | INC TEMP | INC TIME  |
| 01      | Press Edit    |         |          |           |
| 6       | < - To Delete |         |          |           |
| SEGMENT | TEMPERATURE   | RATE    |          | HOLD TIME |



Press the **EDIT** key to delete the segment. If you have made a mistake or change your mind, press any other key to clear the display and continue.


## Programming the Header



Hold down the **EDIT** key and then press the **UP ARROW** key to move to the Header line. If the cursor is not on the program number use the **LEFT ARROW** key to get there.

|         |        |         |          |          |
|---------|--------|---------|----------|----------|
| PROG NO | CYCLES | LINK TO | INC TEMP | INC TIME |
| 01      | 02     | 01      | -9.9     | 00       |

A Program Header consists of a Program Number, the number of Cycles to run and the number of the program to which it should be linked (if any).




If, at any time, you do not want to change anything else in the Header but you need to program more segments, hold the **EDIT** key down and press the **DOWN ARROW** key. Then continue as for programming a segment.

## The Program Number

If the program selected is new, the Header is preset for one unlinked cycle. For simple programs, this means that it is not necessary to program the Header.

| PROG NO | CYCLES | LINK TO | INC TEMP | INC TIME |
|---------|--------|---------|----------|----------|
| 0 1     | 0 1    | E       | 0 . 0    | 0 0      |



Change the number by pressing the **UP ARROW** or **DOWN ARROW** keys. Should you have pressed the **LEFT ARROW** key too often when getting onto the program number, you may not be able to change the program number. In this case press the **RIGHT ARROW** key and you should be able to continue.

If you increase the number beyond 50, the Program Number rolls back round to 1. In the same way, if you decrease the number below 1, the Program Number rolls back round to 50.




When you have the correct number, press the **RIGHT ARROW** key to move to the next field.

## Cycles

The default is 1; the maximum number of Cycles possible is 99.

| PROG NO | CYCLES | LINK TO | INC TEMP | INC TIME |
|---------|--------|---------|----------|----------|
| 0 1     | 0 3    | E       | 0 . 0    | 0 0      |



Change the number by pressing the **UP ARROW** or **DOWN ARROW** keys.




When you have the correct number of cycles, press the **RIGHT ARROW** key to move to the next field.

## Link To Program

Once a program has run for the correct number of Cycles, it may be linked to another program by specifying its number in the Link To field.

| PROG NO | CYCLES | LINK TO | INC TEMP | INC TIME |
|---------|--------|---------|----------|----------|
| 0 1     | 0 1    | 2 3     | 0 . 0    | 0 0      |



If you wish to link one program to another, enter the number of the next program to run by pressing the **UP ARROW** or **DOWN ARROW** keys. Any number between 1 and 50 may be entered, provided the corresponding program exists.

Programs may also be linked to themselves to create an endless loop. The program will run indefinitely. To do this, enter the current program number in the Link To field.

| PROG NO | CYCLES | LINK TO | INC TEMP | INC TIME |
|---------|--------|---------|----------|----------|
| 1 4     | 0 1    | 1 4     | 0 . 0    | 0 0      |

The final program of a linked list of programs should be set to Link To 'E' in the Header to finish the run.

| PROG NO | CYCLES | LINK TO | INC TEMP | INC TIME |
|---------|--------|---------|----------|----------|
| 0 1     | 0 1    | E       | 0 . 0    | 0 0      |




If linking is not necessary, accept the default of E by pressing the **RIGHT ARROW** key to move to the Increment field.

The Increment Temperature and Increment Time are described as part of the segment, see page 17.

If you have finished programming the unit go to the section 'Running a Program' below.

## Deleting a Program

To delete an existing program, make sure you are in Operating mode, and the cursor is on the program number you wish to delete. Hold down the **EDIT** key and press the **LEFT ARROW** key. A message appears asking you to confirm the deletion:



| PROG NO | CYCLES      | LINK TO | INC TEMP   | INC TIME |
|---------|-------------|---------|------------|----------|
| 01      | <           | -       | Press Edit |          |
|         |             |         | To Delete  |          |
| SEGMENT | TEMPERATURE | RATE    | HOLD TIME  |          |



Press the **EDIT** key to delete the program. The deleted program will return to default values of 1 segment and 1 unlinked cycle with an increment/decrement of 0.

## Running a Program




If you want to run a particular program have the program number on display then press the **START/STOP** key. The following message appears on the display:

| PROG NO | CYCLES      | LINK TO | INC TEMP  | INC TIME |
|---------|-------------|---------|-----------|----------|
| I       | N           | T       | P         | R        |
| H       | E           | A       | T         | E        |
| S       | E           | T       |           |          |
| H       | E           | A       | T         | E        |
| L       | I           | D       | O         | N        |
|         |             |         |           |          |
| SEGMENT | TEMPERATURE | RATE    | HOLD TIME |          |

ON / OFF

If the selected program has no defined segments, the following error message appears on the display.

| PROG NO | CYCLES      | LINK TO | INC TEMP  | INC TIME |
|---------|-------------|---------|-----------|----------|
| 01      | 02          | 01      | -9.9      | 00       |
| P       | r           | o       | g         |          |
| N       | o           | t       | D         | e        |
| f       | i           | n       | e         | d        |
|         |             |         |           |          |
| SEGMENT | TEMPERATURE | RATE    | HOLD TIME |          |



Press any key to clear the screen. Move to the Program Number field and use the **UP ARROW** and **DOWN ARROW** keys to select an existing program to run.

As the unit runs, the program line shows the number of the current program, the number of remaining Cycles, the next program to Link To (or 'E'nd) and the increment/decrement temperature and the increment/decrement time for the specified segment. The segment line shows the current sample temperature, the current Heating Rate and the time remaining before the end of the segment.

The Hold Time will start to count down when the sample temperature gets to within 0.5°C of the Set Point temperature. When the Hold Time reaches zero, the segment ends. The unit will then run the next segment (if any), the next cycle (if any), the linked-to program (if any), or the run will end.



If you do not wish to continue the run, you may stop it at any time by pressing the **START/STOP** key. The following message is displayed and the unit is brought back to ambient temperature.

| PROG NO                 | CYCLES      | LINK TO | INC TEMP  | INC TIME |
|-------------------------|-------------|---------|-----------|----------|
| 0 1                     | 0 2         | 0 1     | - 9 . 9   | 0 0      |
| P r o g . S t o p p e d |             |         |           |          |
| SEGMENT                 | TEMPERATURE | RATE    | HOLD TIME |          |



Press any key to clear the message. The unit remains in Operating mode.

When all the segments have been run, the program links to the program specified in the Header, if any. If this program has no segments, the message **Link Error** appears, the unit automatically stops and the program run ends.

| PROG NO             | CYCLES      | LINK TO | INC TEMP  | INC TIME |
|---------------------|-------------|---------|-----------|----------|
| 0 1                 | 0 2         | 0 1     | - 9 . 9   | 0 0      |
| L i n k   E r r o r |             |         |           |          |
| SEGMENT             | TEMPERATURE | RATE    | HOLD TIME |          |

A program is completed when all the segments have been run and no link is found to another program. At this point, the sounder beeps fifty times and the LCD displays the message:

| PROG NO                     | CYCLES      | LINK TO | INC TEMP  | INC TIME |
|-----------------------------|-------------|---------|-----------|----------|
| 0 1                         | 0 1         | E       | 0 . 0     | 0 0      |
| E n d   O f   P r o g r a m |             |         |           |          |
| SEGMENT                     | TEMPERATURE | RATE    | HOLD TIME |          |



Press any key to stop the beeps and clear the message. The unit then cools to near ambient temperature. If the Progene is required to run at ambient temperature, note that the minimum temperature obtainable will be within 1°C of ambient after six minutes. The unit remains in Operating mode.

The fan remains on for five minutes and then switches off automatically.

## Pre-Heat program

To prevent condensation forming on the micro-tube walls during the initial heat up cycle a pre-heat program may be used. Set up a 40°C for 2 minutes program in the Progene memory. This will allow the heated lid to increase in temperature while the block is held at 40°C. Each time you start a sequence, link the pre-heat program to the first program in the sequence.

| PROG NO | CYCLES      | LINK TO | INC TEMP  | INC TIME |
|---------|-------------|---------|-----------|----------|
| 0 7     | 0 1         | 0 1     | 0 . 0     | 0 0      |
| 1       | 4 0 . 0     | MX      | 0 2 m     | 0 0      |
| SEGMENT | TEMPERATURE | RATE    | HOLD TIME |          |





At this stage do not put tubes into the block. Start the Progene by pressing the **START/STOP** key. This allows the heated lid to reach working temperature before any samples are put into the unit and cycled. This will minimise any losses during the first few cycles of the program. **WARNING:** Care should be taken as the heated lid will now be HOT.



When the unit has run its 2 minute cycle (this can be observed on the readout screen) press the **PAUSE** button. Load the sample tubes into the block, put the hot box in place and close the heated lid. Press the **PAUSE** button again and the unit will continue linking from the Pre-Heat program to the thermal cycling program.



The heated lid remains at maximum temperature until the completion of the thermal cycling program.

Note: if a temperature of below 35°C is programmed the heated lid will not switch on.

## Printing Profiles

---

As the Progene runs, profile information is sent to the parallel printer port. This information defines the times and temperatures at various points during the run. A range of events creates data which is used to create a profile of the run.

If you require printed output, make sure that the printer is plugged in and set on line *before* pressing the **START/STOP** key.

If the printer subsequently goes off line, the Progene will attempt to send data to the printer but will not succeed. A short time-out of about three seconds will elapse before the Progene gives up trying. The remainder of that event's data is then discarded. The Progene will attempt to communicate with the printer on the next event. Each event that cannot be printed causes the sounder to beep, giving the user an indication that the printer is off line.

If a printer is *not* connected or is *off-line* when the **START/STOP** key is pressed, then the unit does not attempt to output to it even if a printer is subsequently plugged in. If the printer is unable to accept the incoming profile data for any reason, the data is lost. However, the operation of the Progene is not impeded by a non-functioning printer.

Note that profiles cannot be printed out during calibration.

The events which are used to generate profile information are:

|                           |                                                                                                                    |
|---------------------------|--------------------------------------------------------------------------------------------------------------------|
| <b>Start key</b>          | A Start of program event is generated on first pressing the <b>START/STOP</b> key.                                 |
| <b>Stop key</b>           | A subsequent press of the <b>START/STOP</b> key stops a run prematurely. This event generates a printer form feed. |
| <b>Start of program</b>   | Whenever a new program starts. This event generates a Start of cycle event.                                        |
| <b>Start of cycle</b>     | Whenever the current program starts a new cycle. This event generates a Start of Segment event.                    |
| <b>Start of segment</b>   | Whenever a new segment starts.                                                                                     |
| <b>Start of Hold Time</b> | Whenever the current segment reaches the Hold Time window.                                                         |

|                       |                                                                                                                                                                         |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>End of program</b> | Whenever the run ends due to the program finishing. This event generates a printer form feed.                                                                           |
| <b>Pause on</b>       | Whenever the <b>PAUSE</b> key is first pressed to pause a running program.                                                                                              |
| <b>Pause off</b>      | Whenever the <b>PAUSE</b> key is subsequently pressed to end a pause period.                                                                                            |
| <b>Link error</b>     | When the run comes to an end due to a Link error. This event generates a printer form feed.                                                                             |
| <b>Fatal error</b>    | When a fatal error is detected, due to either the temperature sensor going open circuit or short circuit, or if the unit goes over the maximum permissible temperature. |

A printed profile is 80 columns wide and uses only standard characters in the ASCII range 1 to 127: thus all common dot matrix, pin fed, continuous stationery printers can be used.

An example of a typical printed profile is shown here:

|                                        |               |                |      |              |                      |                                                     |                           |              |                         |
|----------------------------------------|---------------|----------------|------|--------------|----------------------|-----------------------------------------------------|---------------------------|--------------|-------------------------|
| TECHNE<br>BLOCK TYPE B                 |               |                |      |              |                      | PROGENE<br>VERSION PGN 01V04<br>11th September 1995 |                           |              |                         |
| TEMPERATURE UNITS: deg C               |               |                |      |              |                      |                                                     |                           |              |                         |
| PROGRAM: 3<br>CYCLES: 20<br>LINK TO: 1 |               |                |      |              |                      |                                                     |                           |              |                         |
| CYCLE 1                                |               |                |      |              |                      |                                                     |                           |              |                         |
| SEG.<br>NO.                            | START<br>TIME | START<br>TEMP. | RATE | TEMP<br>INC. | HOLD<br>TIME<br>INC. | HEATING<br>COOLING<br>TIME                          | SET PT.<br>START<br>TEMP. | HOLD<br>TIME | SET PT.<br>END<br>TEMP. |
| 1                                      | 00:00:00      | 31.3           | +60  | 0.0          | 00                   | 00:01:11                                            | 98.5                      | 00:00:30     | 99.0                    |
| 2                                      | 00:01:41      | 99.0           | -50  | +1.0         | 10                   | 00:00:56                                            | 55.5                      | 00:00:30     | 55.0                    |
| END                                    | 00:02:07      |                |      |              |                      |                                                     |                           |              |                         |

Events other than End of program would produce the following type of lines:

|       |          |  |  |  |  |  |  |  |  |
|-------|----------|--|--|--|--|--|--|--|--|
| PAUSE | 00:03:34 |  |  |  |  |  |  |  |  |
| STOP  | 00:03:45 |  |  |  |  |  |  |  |  |

and so on

Note the following:

- The second line shows the block type detected and the software version number.
- At the start of every program (i.e. when the start button is pressed or due to a link), the program header data is displayed. This consists of the program number, the programmed number of cycles and the link to program number.
- At the start of each cycle, the cycle number is shown.

- The start time is the total elapsed time since the start key was pressed. Therefore, the first start time is always zero.
- The heating time is the time calculated from the start of the segment until the sample temperature reaches the Hold Time window.
- The Hold Time is the time calculated from the start of the hold until the start of the next segment or the end of the program.
- The Rate is prefixed with either a '+' or '-' to indicate a heating (+) or cooling (-) segment.

## Computer communications

---

Using software such as PROCOMM, print profile information can be transferred and stored on file using a computer. This information can then be recalled for future reference. You will need an RS232 lead, which Techne can supply, between the Progene and the computer.

### Communication Rates

The Progene operates at 1200 Baud, 8 data bits, with 1 start/stop bit and no parity. RTS/CTS is implemented.

### Save File

Key presses are shown below in square brackets[ ].

To create a file which records the information as the Progene operates:

When PROCOMM is booted press [PAGE DOWN] and then [7].

When the computer asks for a file name [type in your own file name] followed by [ENTER].

The file is shown on the screen as it is sent from the Progene.

When the down-load is complete, the file is in the same directory as PROCOMM.

## Warnings and Messages

Messages are displayed on the LCD screen to give users prompts and warnings, or advise of errors or incorrect operation. There are two main sources of errors which cause a message to be displayed: incorrect user input (non-fatal errors) and system failure (fatal errors).

### User Errors

These errors occur if you accidentally press the wrong key. In some cases, a beep is sounded to warn of the error. In others, a message is displayed and you must press any key to clear the LCD screen and continue.

### System Messages

These messages inform you that certain events have taken place, for example when the end of a program has been reached. Simply press any key to clear the message and continue.

### Run Time Tests

Certain parameters are continuously checked while the Progene is running, including:

Temperature sensor open circuit, temperature sensor short circuit, or a fault in the circuitry will cause the unit to stop and the following message will appear.

| PROG NO                                | CYCLES      | LINK TO | INC TEMP  | INC TIME |
|----------------------------------------|-------------|---------|-----------|----------|
| <b>I n t . S e n s o r   F a u l t</b> |             |         |           |          |
| <b>R e f e r   t o   M a n u a l</b>   |             |         |           |          |
| SEGMENT                                | TEMPERATURE | RATE    | HOLD TIME |          |

A long beep is heard and the keyboard becomes inactive. The unit is inoperative and the Progene attempts to return to ambient temperature.

Switch off the unit and allow it to cool down.

If the message:

| PROG NO    | CYCLES       | LINK TO    | INC TEMP     | INC TIME   |
|------------|--------------|------------|--------------|------------|
| <b>0 7</b> | <b>0 1</b>   | <b>0 1</b> | <b>0 . 0</b> | <b>0 0</b> |
| <b>1</b>   | <b>U / R</b> | <b>MX</b>  | <b>0 2 m</b> | <b>0 0</b> |
| SEGMENT    | TEMPERATURE  | RATE       | HOLD TIME    |            |

appears it means that the sensor has sensed a temperature which is 'under range'.

Any of these messages could mean that the sensor in the block has gone wrong or there is a fault on the PCB. If you have a spare block try, first of all, swapping the blocks. If the message re-appears it is likely that there is a fault on the PCB. If the message disappears then it is likely that there is a fault on the first block. Return either the block or the unit to your Techne dealer, see Page 31..

## Over-temperature Cut-out

Your Progene is fitted with a circuit to protect it from overheating. The unit constantly checks that the block temperature does not exceed its maximum. If for some reason this temperature is exceeded, all power to the block is cut.

You should immediately switch off the unit and allow it to cool. The unit then resets itself automatically. Check for any obvious causes of overheating before switching it back on.

Repeated cutouts indicate a serious fault and you should return the unit to your supplier for repair.

## Thermal Fuse

The block is also fitted with a thermal fuse. Should the temperature rise so that this blows the unit will still indicate that it is calling for heat but the block temperature will fall.

If this happens you should switch off the unit and allow it to cool. Check for obvious causes of overheating before switching the unit back on. If you have a spare block try, first of all, swapping the blocks. If the message re-appears it is likely that there is a fault on the PCB. If the message disappears then it is likely that there is a fault on the first block. Return either the block or the unit to your Techne dealer or to Techne, see Page 31.

## Auto restart

If the mains supply is interrupted while a program is running the program will restart automatically when the supply returns, continuing from the point at which it was interrupted. First of all the following screen will appear temporarily:

| PROG NO                          | CYCLES      | LINK TO | INC TEMP  | INC TIME |
|----------------------------------|-------------|---------|-----------|----------|
| <b>P O W E R   F A I L U R E</b> |             |         |           |          |
| <b>D E T E C T E D</b>           |             |         |           |          |
| SEGMENT                          | TEMPERATURE | RATE    | HOLD TIME |          |

When the restart occurs the screen display will show the date and time of the interruption, the date and time of the restart, and the duration of the break. A typical restart screen is shown below:

| PROG NO                              | CYCLES      | LINK TO | INC TEMP  | INC TIME |
|--------------------------------------|-------------|---------|-----------|----------|
| <b>P W R   F L   0 0 : 0 0 : 1 4</b> |             |         |           |          |
| <b>a t   2 1 : 2 0   -   2 9 / 1</b> |             |         |           |          |
| SEGMENT                              | TEMPERATURE | RATE    | HOLD TIME |          |

This display will remain on the screen until the **mode** key is pressed. It will then revert to the Monitoring screen and show the current state of the system (the program will be running or will have completed).

To advance to the Editing menu press the **mode** key.

## OPTIONS MODE


Options mode allows you to set additional features, such as Printer port, printing out the 'current' program, Date Format, Time, Date, resetting the defaults, and whether the Heated Lid is on or off.



When the unit is switched on, it automatically goes into Operating mode. Press the **MODE** key to move into Options mode.


The following screen appears:

|                      |             |         |           |                |
|----------------------|-------------|---------|-----------|----------------|
| PROG NO              | CYCLES      | LINK TO | INC TEMP  | INC TIME       |
| <b>OPTIONS</b>       |             |         |           |                |
| <b>P r i n t e r</b> |             |         |           | <b>P P / S</b> |
| SEGMENT              | TEMPERATURE | RATE    | HOLD TIME |                |



In Options mode, pressing the **RIGHT ARROW** and **LEFT ARROW** keys moves you between the available features. Since the LCD panel has only two lines, the display scrolls down to show the other options, one at a time, in the following order:

|                          |                    |                        |                       |
|--------------------------|--------------------|------------------------|-----------------------|
| <b>P r i n t e r</b>     | <b>P r o g</b>     | <b>Y E S</b>           | <b>YES / NO</b>       |
| <b>D a t e</b>           | <b>F o r m a t</b> | <b>D M Y</b>           | <b>D M Y or M D Y</b> |
| <b>T i m e</b>           |                    | <b>0 0 : 0 0</b>       | <b>hours : mins</b>   |
| <b>D A T E</b>           |                    | <b>0 1 / 0 1 / 9 5</b> |                       |
| <b>R e s e t</b>         |                    | <b>N O</b>             | <b>YES / NO</b>       |
| <b>H e a t e d L i d</b> |                    | <b>O F F</b>           | <b>OFF / ON</b>       |



In general, pressing the **UP ARROW** and **DOWN ARROW** keys toggles between available settings.

### Printer

This option allows you to choose whether the printer is communicating with the serial port (S) or the parallel port (P) .

### Printer Prog

This option allows you to print out the program which was on the screen when you changed to Options Mode. It will print out all the settings for each of the segments of the 'current' program. You must have a printer fitted before the Progene will switch between Yes or No.

### Date Format

This option allows you to choose which format the date is presented in, UK dd:mm:yy or USA mm:dd:yy.

### Time

This allows you to set the time.

### Date

This allows you to set the date in whichever format you chose earlier.

## Reset to Default Values

**Warning: If you choose this option all the existing programs and segments are erased.**

All the system parameters are then reset to their original defaults values, i.e. Increment Segment to 1, and last used program to 1.

The reset process takes several seconds, as all the existing segments and programs must be returned to the original default values. The display indicates which program or segment is currently being reset.

It is important not to switch off the unit during the reset process, to avoid data corruption. If the unit is accidentally switched off, switch it on and select Reset Defaults again.

When all the segments and programs have been reset, the unit automatically restarts, as though the Progene had been switched off and then on again.

## Default Values

The default values for all the fields are automatically set, and it is not possible to enter values outside the predetermined range, as listed in the following table:

|                                    | Minimum    | Maximum      | Default |
|------------------------------------|------------|--------------|---------|
| <b>Program Header</b>              |            |              |         |
| Program No.                        | 01         | 50           | 01      |
| Cycles                             | 01         | 99           | 01      |
| Link To                            | 01         | 50           | 'E'nd   |
| Increment/decrement Temp           | -5.5°C     | 5.6°C        | 00      |
| Increment/decrement time           | -99sec     | 99sec        | 00      |
| <b>Segment</b>                     |            |              |         |
| Segment No.                        | 01         | 09           | 01      |
| Temperature                        | 4.0°C      | 99°C         | 40°C    |
| Heating Rate                       | 1°C/min    | 60°C/min     | MX      |
| Hold Time                          | 00m01(sec) | 99h59(min)   | 00m00   |
| Temperature resolution             |            | 0.1°         |         |
| Heating Rate resolution            |            | 1°/min       |         |
| Hold Time resolution (running)     |            | 1sec         |         |
| Hold Time resolution (programming) |            | 1sec         |         |
| – Hold Time less than one hour     |            | 1sec         |         |
| – Hold Time greater than one hour  |            | 1min         |         |
| Program capacity                   |            | 143 segments |         |

Default values are programmed in a loop, so if you attempt to increment or decrement beyond the upper or lower limit, the values simply 'roll' round.

## Heated Lid

This allows you to choose if the Heated Lid is on or off. The Heated Lid is automatically off if the target temperature is less than 35°C.

## Operating Mode



To return to the Operating Mode, press the **MODE** key again.

## ADDITIONAL INFORMATION

---

Brief fault finding notes and a list of replacement parts are given in this section.

NOTE THAT THIS EQUIPMENT SHOULD ONLY BE DISMANTLED BY PROPERLY TRAINED PERSONNEL. **REMOVING THE OUTER COVER EXPOSES POTENTIALLY LETHAL MAINS VOLTAGES.**

THERE ARE NO USER SERVICEABLE PARTS WITHIN THIS EQUIPMENT.

### Fault Finding

---

Should you have any problems with your Progene which cannot be easily remedied, you should contact your supplier and return the unit if necessary. Please include details of the fault observed and remember to return the unit in its original packing. Techne accept no responsibility for damage to units which are not properly packed for shipping: if in doubt, contact your supplier, giving the full serial number of the unit and software version number (shown when the unit is first switched on).

### Fuses

---

If neither the power light nor displays on the front panel are lit, one of the two fuses may have blown. Check that there is no external cause, such as a faulty plug or lead. Check both fuses and replace the faulty fuse with a new one of the correct value. (Fuse values are given on the label next to the power inlet.) Note that fuses should only be replaced by a qualified electrician.

The holder for the two fuses is built into the mains input socket. First remove the power cable, then gently prise the fuse drawer open with a flat-bladed screwdriver or similar tool.

Each fuse can be removed by using the screwdriver as a lever.

Exchange the faulty fuse in the fuse holder for a working fuse of the correct value. Finally, replace the fuse drawer in the fuse compartment and push the drawer shut.

Fuses which blow repeatedly indicate a serious fault and you should return the unit to your supplier for repair.

### The Heated Lid Over temperature cutout

---

Your Heated Lid is fitted with an independent circuit to protect it from overheating. In the unlikely event of an Over-temperature problem with the lid, the unit is fitted with two thermal fuses which remove power to the heater plate should the temperature exceed 105°C.

### Insulation Testing


---

This equipment is fitted with RFI suppression circuitry. Any check of the electrical insulation by means of high voltage dielectric testing (for example as in BS EN 61010-1) must be carried out using only a DC voltage.

This unit contains semiconductor components which may be damaged by electric field effects.



## Interchangeable Blocks



The blocks can be removed and exchanged for another of the same sort or of a different sort. The software will register the change and calibrate the unit for the new block.

Remove the four screws beneath the unit and drop the block/fan assembly down. Unplug the assembly from the wiring and remove the assembly from the unit. Refitting the block/fan assembly is the reverse procedure, be careful of the wires as you refit the block.

## Accessories

The following accessories can be obtained from Techne or your Techne dealer:

| Item No  | Description                 | Quantity     |
|----------|-----------------------------|--------------|
| FPRBL02  | 0.2ml Tube Block            |              |
| FPRBL05  | 0.5ml Tube Block            |              |
| FMW05    | 5 x 5 Thermowell Plate      | Pack of 25   |
| FTUB02TW | 0.2ml micro tubes           | Pack of 1000 |
| FTUB05TW | 0.5ml Micro tubes thin wall | Pack of 1000 |

## Replacement parts

---

The following replacement parts can be obtained from Techne or your Techne dealer:

| Item N°  | Description                        | Quantity required |
|----------|------------------------------------|-------------------|
| FCABRTUK | Mains cable and plug UK 240V       | 1                 |
| FCABRTEU | Mains cable and Schuko plug 220V   | 1                 |
| FCABRTUS | Mains cable and US 3-pin plug 120V | 1                 |
| FCABRTUS | Mains cable and US 3-pin plug 100V | 1                 |
| 6500128  | Fuse T2A, 220/240V                 | 2                 |
| 6500129  | Fuse T4A, 120V                     | 2                 |
| 6103203  | Hot Box                            | 1                 |

## GLOSSARY

---

|                              |                                                                                                                                                                                                                                                                                                                                                                    |
|------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Block temperature</b>     | The current temperature of the heat transfer block.                                                                                                                                                                                                                                                                                                                |
| <b>Cooling Rate</b>          | The rate at which the temperature of the block decreases in degrees Celsius per minute.                                                                                                                                                                                                                                                                            |
| <b>Cursor</b>                | The flashing rectangle on the LCD panel which indicates in which field the next character is entered.                                                                                                                                                                                                                                                              |
| <b>Cycle</b>                 | One cycle is a complete execution of all segments in a program.                                                                                                                                                                                                                                                                                                    |
| <b>Heating Rate</b>          | The rate at which the temperature of the block increases in degrees Celsius per minute.                                                                                                                                                                                                                                                                            |
| <b>Hold Time</b>             | The duration for which the block is maintained at a given temperature. Note that the clock counter which measures the Hold Time is started when the temperature is within 0.5°C of the Set Point Temperature.                                                                                                                                                      |
| <b>Pause</b>                 | When you press <b>PAUSE</b> , the program halts but maintains the block at the temperature reached immediately before the key was pressed. If this happens while maintaining a 'target temperature', the timer is also halted. (Note that it takes several seconds for the temperature of the samples to reach equilibrium.) Press <b>PAUSE</b> again to continue. |
| <b>Program</b>               | A program is made up of a sequence of segments. The sequence may be executed once or several times.                                                                                                                                                                                                                                                                |
| <b>Ramp Rate</b>             | The term used to denote the heating or cooling rate in degrees per minute.                                                                                                                                                                                                                                                                                         |
| <b>Sample temperature</b>    | The current temperature of the sample which is displayed on the LCD panel while a program is running.                                                                                                                                                                                                                                                              |
| <b>Segment</b>               | A segment is comprised of a target temperature, a Heating or Cooling Rate and a time to hold the target temperature.                                                                                                                                                                                                                                               |
| <b>Set Point Temperature</b> | The temperature which must be reached as indicated in a programmed segment.                                                                                                                                                                                                                                                                                        |

### Programme Record Sheet

| PROG NO |             | CYCLES |           | LINK TO  |          |
|---------|-------------|--------|-----------|----------|----------|
| SEGMENT | TEMPERATURE | RATE   | HOLD TIME | INC TEMP | INC TIME |
| 1       |             |        |           |          |          |
| 2       |             |        |           |          |          |
| 3       |             |        |           |          |          |
| 4       |             |        |           |          |          |
| 5       |             |        |           |          |          |
| 6       |             |        |           |          |          |
| 7       |             |        |           |          |          |
| 8       |             |        |           |          |          |
| 9       |             |        |           |          |          |

### Programme Record Sheet

| PROG NO |             | CYCLES |           | LINK TO  |          |
|---------|-------------|--------|-----------|----------|----------|
| SEGMENT | TEMPERATURE | RATE   | HOLD TIME | INC TEMP | INC TIME |
| 1       |             |        |           |          |          |
| 2       |             |        |           |          |          |
| 3       |             |        |           |          |          |
| 4       |             |        |           |          |          |
| 5       |             |        |           |          |          |
| 6       |             |        |           |          |          |
| 7       |             |        |           |          |          |
| 8       |             |        |           |          |          |
| 9       |             |        |           |          |          |

### Programme Record Sheet

| PROG NO |             | CYCLES |           | LINK TO  |          |
|---------|-------------|--------|-----------|----------|----------|
| SEGMENT | TEMPERATURE | RATE   | HOLD TIME | INC TEMP | INC TIME |
| 1       |             |        |           |          |          |
| 2       |             |        |           |          |          |
| 3       |             |        |           |          |          |
| 4       |             |        |           |          |          |
| 5       |             |        |           |          |          |
| 6       |             |        |           |          |          |
| 7       |             |        |           |          |          |
| 8       |             |        |           |          |          |
| 9       |             |        |           |          |          |

Photocopying this page makes it possible to use it for several sets of programmes.







# **Progene**

## **OPERATOR'S MANUAL**

**Issue 10. Date of issue: 22nd August 2000**

The Techne logo is the trademark of Techne (Cambridge) Limited and Techne Incorporated.

© Techne (Cambridge) Limited, 1995